

# BMW Motorrad

## Maintenance schedule



### 0379 - R 1200 C

00 00 131 BMW Inspection with Annual Inspection (see Maintenance Schedule) (annually, every 20,000 km)

|           |                  |                                  |   |
|-----------|------------------|----------------------------------|---|
| _____     | _____            | _____                            | <b>Equipment trim-level variant:</b><br>0415 - BMW Motorrad Integral ABS (fully integral) |
| Customer  | Registration No. | Odometer reading                 |   |
| _____     | _____            | _____                            |   |
| Order No. | Date             | Mechanic's + Manager's signature |   |

|   |  |
|---|--|
| Reading fault-code memories with the BMW Motorrad diagnostic system                             | <input type="checkbox"/>   |
| Checking clutch fluid level   | <input type="checkbox"/>   |
| 21 00 505 Change the clutch fluid (during maintenance) *)                                       | every four years <input checked="" type="checkbox"/>                   |
| Changing engine oil with engine at operating temperature, replacing oil filter                  | <input type="checkbox"/>   |
| Changing oil in gearbox, warmed to normal operating temperature                                 | <input type="checkbox"/>   |
| 33 00 501 Oil change, rear wheel drive *)   | every two years or every 40,000 km <input checked="" type="checkbox"/> |
| 16 12 503 Replace fuel filter (fairing/fuel tank removed) *)                                    | every 40,000 km <input checked="" type="checkbox"/>                    |
| Replacing intake air filter   | <input type="checkbox"/>   |
| 34 00 616 Changing brake fluid in Integral ABS wheel circuit, front (as part of maintenance) *) | every two years <input checked="" type="checkbox"/>                    |
| 34 00 703 Additional work with ABS: (for changing brake fluid in rear wheel circuit) *)         | <input type="checkbox"/>   |
| 34 00 608 Change brake fluid in entire ABS control circuit (maintenance) *)                     | every four years <input checked="" type="checkbox"/>                   |
| Checking rear wheel bearing play by tilting wheel   | <input type="checkbox"/>   |
| Checking swinging-arm pivot mount   | <input type="checkbox"/>   |
| Checking operation of side-stand switch   | <input type="checkbox"/>   |
| Greasing side stand pivot   | <input type="checkbox"/>   |
| 12 31 657 Repleace belt for generator (as part of maintenance) *)                               | every 40,000 km <input checked="" type="checkbox"/>                    |
| Checking condition of spark plugs   | <input type="checkbox"/>   |
| 12 12 509 Replace all spark plugs (as part of maintenance) *)                                   | every 40,000 km <input checked="" type="checkbox"/>                    |
| Adjusting valve clearance   | <input type="checkbox"/>   |
| Checking freedom of movement of throttle cable and checking for kinks and chafing               | <input type="checkbox"/>   |
| 34 00 650 Brake check for BMW Motorrad Integral ABS (as part of maintenance) *)                 | <input type="checkbox"/>   |
| Checking/adjusting synchronisation  | <input type="checkbox"/>   |

|  |                          |
|--|--------------------------|
| Checking tyre pressures and tread depth          | <input type="checkbox"/> |
| Checking lights and signalling equipment         | <input type="checkbox"/> |
| Test ride as final inspection and function check | <input type="checkbox"/> |
| Confirming BMW Service in on-board documentation | <input type="checkbox"/> |

\*) Billed as a separate item

not as per the normal schedule

BMW Motorrad, UX-VA-4  
18.05.06

BMW recommends 